

## NOCOMAX

## EASY

The aerial surface bio-disinfection device for large volumes.



■ ■ ■ Manufactured in France by OxyPharm according to ISO 13485.

The **Nocomax Easy** is a surface biodisinfection unit developed for industrial use, which can treat volumes of 500 to 20,000 m<sup>3</sup>.

It ensures aerial surface disinfection or disinsectisation when used along with our Nocolyse or Oxyppy ranges. A dry fog allows a uniform treatment of every cm<sup>2</sup> of surfaces, as a preventive or curative measure.

It is suitable for all fields of activity: communities, health, pharma-cosmetics, agri-food, transport, veterinary, tourism, trade and distribution, etc.

**EASY TO USE**  
Easy adjustment for the volume of the room to be treated thanks to its touchpad.

**ECONOMICAL**  
Very small amount of product required.

**GUARANTEED TIME SAVING**  
No preparation required before treatment (except for cleaning) or after treatment (no need to wipe or ventilate).

## COMPATIBILITY

- Disinfectant cans (20 L): Nocolyse, Nocolyse+, Nocolyse Food, Nocolyse One Shot.
- Insecticide cans (20 L): Oxyppy, Oxyppy+.

## PRECAUTIONS FOR USE

Read all product information before use. Instructions for use are available on request by email: [info@oxypharm.net](mailto:info@oxypharm.net)

## TECHNICAL CHARACTERISTICS

Dimensions (L x W x H cm)	70 x 58 x 100 cm
Empty weight	43.4 kg
Packaging	
- Dimensions (L x W x H cm)	110 x 70 x 120 cm
- Weight	70 kg
Maximal treatment volume	20,000 m <sup>3</sup>
Turbine speed	22,000 rpm
Output speed of the mist	80 m/s
Average liquid flow rate	6,000 ml/h
Storage conditions	
- Temperature	0°C to 50°C
- Hygrometry	25% to 75%
Power	2000 W
Average particle size	<5 μ

## REFERENCES

DEVICE	REFERENCE
Nocomax Easy	3100.100
Nocomax Easy with adjustable nozzles	3100.101